

Quick Reference

- ❖ Before putting up drywall, be sure to install the thermostat wires and the floor sensor tubing. The wires need to be routed from the thermostat location to the mechanical room where the system will be installed. If possible, you should use LVT 18/3 thermostat wire.
- ❖ Before pouring the concrete, be sure to pressurize the tubing using the gauge provided.
- ❖ You need to set aside sufficient space for the system, based on its size. It should be accessible and the room layout must comply with the clearances specified in the electrical and plumbing codes.
- ❖ Be sure to fully bleed the system before turning it on. Once you have finished bleeding the system, verify that the air eliminators are open and that the pressure on the boiler and injection valve is between 10 and 15 PSI. This will help prevent any damage to the system.
- ❖ When your panel arrives, verify that it includes all the right parts and that it has not been damaged. After 30 days, HCW will no longer be responsible for any missing or broken parts.
- ❖ In the case of a system with a gas boiler, consult with a gas contractor to verify that the space where the panel will be installed meets chimney installation standards.
- ❖ In the case of a dual-energy system, consult with your electrician or plumber to verify that an application for the dual-energy rate will be submitted to your electricity supplier.
- ❖ Always hire a licensed contractor for gas, electrical and plumbing work.
- ❖ Be sure to read the equipment manuals provided for installation and take note of the recommendations and settings they specify.
- ❖ For installation instructions, videos, manuals and wiring diagrams, please visit the “Installation” section of our website at <https://plancherchauffant.com/>.